




Retention Loops



Retention Loop

O-ring




Cable Sleeves

Cable

Retention Loop



Tri-glide Buckle



Tab

CAM Buckle

Loading the RIP-Harness

1. lay the inside of the belt face down; lay the shoulder harness on top of the belt as shown

2. pull the **Retention Loops** on the belt through the metal **O-rings** on the lower part of the shoulder strap

3. slide the **Cable** through the **Cable Sleeve**; pull the **Retention Loop** through the grommet; slide Cable through Retention Loop and into next Cable Sleeve


4. repeat until all three O-rings are attached, when *threading Cable through the middle O-ring Retention Loop, be sure the metal **Tri-glide Buckle** and strap both face against the pack, as shown*

5. place the thick **Tab** on the Side Release buckle assembly into the belt's **CAM Buckle** and close

pull Release Handle straight out with left hand to drop RIP-Harness



Tab



Velcro Tab



6. tuck **Tab** of Padded Release Handle under CAM Buckle on cable side

7. cover cable and cord with Velcro tab

8. lay Padded Release Handle over CAM Buckle and tuck the second tab underneath



Padded Release Handle should look as shown above when finished



pull RIP-Leash straight up and away from body with right hand to deploy the fire shelter